




- ① AT SLOPED OR CURVED CONDITIONS, INDEX MAIN TEE WITH FASTENER FROM BELOW.
- ② INSERT HANGER BRACKET/PIVOT ASSEMBLY ONTO MAIN TEE AND ROTATE TO ENGAGE TWIST CLIP.
- ③ FEED FIRST TAVOLA PRIME BEAM HALFWAY ONTO HANGER BRACKET AND SECURE WITH TWO (2) MIN #6 FASTENERS.
- ④ REMOVE LINER FROM DOUBLE-SIDED ADHESIVE ON BOTTOM SPLICE PLATE AND SECURE HALFWAY INTO FIRST TAVOLA PRIME BEAM.
- ⑤ FEED SECOND TAVOLA PRIME BEAM ONTO HANGER BRACKET ASSEMBLY AND BOTTOM PLATE AND SECURE WITH TWO (2) MIN #6 FASTENERS.
- ⑥ ENSURE TAVOLA BEAM IS PLUM AND TIGHTEN 1/4"-20 NYLOCK NUT.

NON-SPLICE LOCATIONS: ONLY TWO (2) FASTENERS (1 PER SIDE) ARE REQUIRED AND BOTTOM PLATE IS OMITTED.



*VERTICAL SUPPORT OMITTED FOR CLARITY
 **2" X 6" BEAM SHOWN, ALL SIZES SIMILAR