

-
- The diagram illustrates the four steps of baffle splice installation:
- 1** INSERT BAFFLE SPLICE HALFWAY INTO BAFFLE.
 - 2** SECURE WITH (2) TWO MIN #10 TEK SCREWS, BY OTHERS.
 - 3** SLIDE SECOND BAFFLE OVER SPLICE AND TIGHT AGAINST FIRST BAFFLE.
 - 4** SECURE REMAINING SIDE WITH (2) TWO MIN #10 TEK SCREWS, BY OTHERS.
- BAFFLE SPLICE INSTALLATION**
SCALE: NOT TO SCALE

SCALE: NOT TO SCALE

- ① APPLY CONSTRUCTION ADHESIVE TO INTERNAL EDGES OF END CAP.
- ② INSERT END CAP INTO BAFFLE AND REMOVE ANY VISIBLE ADHESIVE. SECURE CAP UNTIL ADHESIVE SETS.
-
- END CAP FINISHES**

PAINTED & POWDER COATED

DECORATED WOOD FINISH (POWDER COATED)

SCALE: NOT TO SCALE

*STRAIGHT BEAM PROFILE SHOWN, VERTICALLY CURVED BEAM PROFILE SIMILAR

**5015 Oakbrook Parkway, Suite 100
Norcross, GA 30093
800-366-4327 / 770-806-9557
fax: 770-806-0214**

www.hunterdouglascontract.com

MATERIAL: EXTRUDED ALUMINUM ALLOY 6063-T5
FINISHES: PAINT / POWDER COAT / DECORATED WOOD
PERFORATION: NOT AVAILABLE

Techstyle®
ACOUSTICAL CEILINGS

DECIMAL: .0 +/- .060
.00 +/- .030
.000 +/- .010

FRACTIONAL: +/- $\frac{1}{32}$ "

ANGULAR: +/- $\frac{1}{2}^\circ$ (.5°)

PROJECT: HIGH PROFILE SERIES VERTICALLY CURVED SPECIFICATIONS
DRAWING NUMBER: HPS-VCURVE-A1.4
PART NUMBER: N/A
SCALE: AS SHOWN
DATE: 8/26/14
DRAWN BY: HDAP ENGINEERING