


- ① LIFT HANGER BRACKET ASSEMBLY INTO POSITION ON MAIN TEE AND SQUEEZE SCISSOR CLIP ONTO MAIN TEE WEB.
- ② FEED FIRST TAVOLA PRIME BEAM HALFWAY ONTO HANGER AND SECURE WITH TWO (2) MIN #6 FASTENERS (BY OTHERS).

- ③ REMOVE LINER FROM DOUBLE-SIDED ADHESIVE ON BOTTOM SPLICE PLATE AND SECURE HALFWAY INTO FIRST TAVOLA PRIME BEAM.
- ④ FEED SECOND TAVOLA PRIME BEAM ONTO HANGER BRACKET ASSEMBLY AND BOTTOM PLATE. SECURE WITH TWO (2) MIN #6 FASTENERS.

NON-SPLICE LOCATIONS: ONLY TWO (2) FASTENERS (1 PER SIDE) ARE REQUIRED AND BOTTOM PLATE IS OMITTED.



5015 Oakbrook Parkway, Suite 100
Norcross, GA 30093
T 800.366.4327
F 770.806.0214
HDarchitectural.com

All rights reserved. This drawing is the property of Hunter Douglas. It may not be copied or multiplied, neither wholly nor partly. It may not be submitted for perusal to third parties.

SPECIFICATIONS

(unless noted otherwise)

MATERIAL: .025" | .032" | .040" ALUMINUM
FINISH: PAINT | POWDER COAT | DECORATED WOOD FINISH | WOOD VENEER
PERFORATION: NON-PERFORATED | #106 | #119

HANGER BRACKET ASSEMBLY INSTALLATION

PROJECT: TAVOLA PRIME PRODUCT SPECIFICATIONS
DRAWING NUMBER: TAVOLA-PRIME-A1.4
SCALE: NOT TO SCALE
DRAWN BY: HDA ENGINEERING
DATE: 8/25/17