



- ① SLIDE T-GRID BRACKET INTO SUSPENSION SLOT OF BAFFLE.\*
- ② LIFT BAFFLE ASSEMBLY UP TO MAIN TEE. ENSURE MAIN TEE FLANGE SLIDES UNDER HORIZONTAL FLANGE OF T-GRID BRACKET AND VERTICAL FLANGE OF T-GRID BRACKET IS ON THE OUTSIDE OF MAIN TEE BULB.
- ③ ADJUST BAFFLE ASSEMBLY TO FINAL POSITION ALONG MAIN TEE AND IF POSSIBLE, ALIGN WITH PRE-PUNCHED MAIN TEE HOLES. IF HOLES ARE NOT COMPATIBLE, FIELD DRILL 1/4" DIA. HOLE.
- ④ SECURE T-GRID BRACKET TO MAIN TEE WITH FACTORY-SUPPLIED 1/4"-20 BOLT AND WING NUT. USE FACTORY-SUPPLIED SPLIT LOCK WASHER ON WING NUT SIDE.
- ⑤ SLIDE BAFFLE INTO FINAL POSITION AND TIGHTEN SET SCREW.



\*1-1/2" X 6-3/8" BEAM PROFILE SHOWN, ALL PROFILES SIMILAR  
 \*\*VERTICAL SUPPORT OMITTED FOR CLARITY

**SPECIFICATIONS**  
 (unless noted otherwise)

MATERIAL: EXTRUDED ALUMINUM ALLOY 6063-T5  
 FINISH: PAINT | POWDER COAT | DECORATED WOOD FINISH | WOOD VENEER |  
 WILSONART LAMINATE  
 PERFORATION: NOT AVAILABLE

**T-GRID BRACKET INSTALLATION**

PROJECT: HIGH PROFILE SERIES PRODUCT SPECIFICATIONS  
 DRAWING NUMBER: HPS-A1.10  
 SCALE: NOT TO SCALE  
 DRAWN BY: HDA ENGINEERING  
 DATE: 9/8/17